



Installation Procedure

1. Assemble the bracket
2. Install the Z type plate to the beam, not tighten
3. Hang the box to the bracket, and the connecting plate that interferes with the wall-mounted strip needs to be removed
4. Tighten the Z type plate and the cabinet with M8*20 screws
5. Tighten the mounting screws between the Z type plate and the beam.



Installation Diagram			
<small>TITLE</small>			
150 Inch I-TV			
<small>SIZE</small>	<small>CAGE CODE</small>	<small>DWG NO</small>	<small>REV</small>
A3	1	16082023ML	
<small>SCALE</small>	<small>SHEET</small>		
1			